

FREEVIEWSHOP

Firmware Upgrade instructions for the Hyundai AH-3110.

STEP 1

Download the AH3110PVR_*. file and copy it to your FAT32 formatted USB Memory Stick.

STEP 2

Insert the Memory Stick into the Hyundai AH-3110 front panel USB Port.

STEP 3

Press **OK** to start the upgrade.



STEP 4

Enter the password (Default: 0000). Do not turn the power off until this step is complete and the AH-3110 has been upgraded, the AH-3110 will reboot after the upgrade by itself.

