

FREEVIEWSHOP

Installation Instructions for a Hex Crimp Belling Lee Connector.

Step 1)

Strip 5mm of Jacket (Usually Black PVC) Shield (Braded Shielding and Aluminum Foil) and Dielectric (White gas injected PE foam) of the cable leaving only the center conductor sticking out.

Step 2)

Strip 5mm of the Jacket only.

Step 3)


Fold the braded shield over the Jacket, Do not do anything with the bonded foil shield.

Step 4)

Check there are no loose wires that could cause a short between the center conductor and the Shield.

Step 5)

Push on the Belling Lee Connector.



Step 6)

Check which size Hex crimp is appropriate for the connector and crimp the connector on by pressing the levers of the Hex Crimping Tool together.

