

FREEVIEWSHOP

Installation Instructions for Installing an OPTUS D1/C1/D2 bracket on a 90cm dish lined up on OPTUS C1

Step 1: Install the bracket and D1 and D2 LNBS as shown i.e. the D2 LNB will be higher up and to the left of the C1 LNB and the D1 LNB will be lower down and to the right:



Step 2: remove the cable from the C1 LNB and attach it to the newly installed D2 LNB.

Step 3: Line up the D2 LNB using a Sat Finder or the receiver select the 12407Mhz V Pol SR:30000 TP and Rotate the LNB bracket until maximum Signal Quality is obtained. Now rotate the LNB (adjust LNB skew) until maximum Quality is obtained. Tighten the Screws.

Step 4: remove the cable from the C1 LNB and attach it to the newly installed D2 LNB.

Step 5: Check the D1 LNB is working fine using the receiver select the 12483Mhz H Pol SR:22500 TP and check the signal strength and quality are Ok.