

FREEVIEWSHOP

Firmware Upgrade instructions for the Ultraplus HD PVRs.

Download the firmware (*.ird) onto a USB Memory stick.

If you want to retain your channel and satellite configuration you can export your own channel data to a file by using MENU > System Tools > Data Transfer > Transfer Service Data to USB storage (Don't forget to press the red button afterwards to safely remove the device).

Once you have the *.ird file on you memory stick, insert the memory stick into the Ultraplus.



Press the Red button on the remote control to load the update. After it has finished you will see the "Download OK" message, the Ultraplus will reboot.

You will now see the progress of writing the software to flash memory on the front panel display, once it has completed this it will start back up as normal. You can remove the memory stick now.

Press the Menu button on the remote control and use the arrow keys to navigate to System Recovery and press OK.




Press the OK button on the remote control to restore to factory default and enter the PIN Code (Default: 0000)



Press the OK button to select English



You will be asked if you wish to restore to stored position, use the < button to select Yes and press OK



You will need to set the time for New Zealand after performing that step, to do that press Menu and navigate to Configuration and select Time Setting



You should select +12:00 for the Local Offset and New Zealand for Daylight Savings then Exit



If the channels are not in the correct order then press OK and then press the Blue button (for Service List option) Scroll to Local channel number and turn the setting to off. The channels will be in the correct order again.

