

FREEVIEWSHOP

Instructions for setting the skew for a Pacific Satellite C Band LNB.

As the signal broadcast from the Intelsat 5 satellite is polarized, it is critical the skew is set correctly.

To use the Pacific Satellite 5150 L.O. C Band LNB on the Intelsat 5 satellite the skew should be set so the cable will attach to the LNB at 11 o'clock looking into the dish from the front, this is shown below, if you are using a 90cm offset dish it is also important to use an offset scalar ring on the LNB.



FREEVIEWSHOP

☎ 09-8175105

🌐 www.freeviewshop.co.nz
@ sales@freeviewshop.co.nz