

FREEVIEWSHOP

Installation Instructions for using an Ultraplus F-9000HD PVR with an existing dish for Freeview reception.

NOTE: If you have a standard definition TV press resolution on the remote control until you see 576i displayed on the VFD display of the Ultraplus F-9000HD PVR.

The Ultraplus F-9000HD PVR is pre configured for a Satellite Dish aimed at OPTUS D1 (Freeview and Sky), Plug your set top box in and turn it on and select the appropriate AV input on your TV. The Ultraplus F-9000HD PVR is pre configured for an 11300MHz L.O. LNB. If you see the "No Signal!" message when you select TV One and TV3 you probably don't have an 11300MHz L.O. LNB and should try changing the LNB L.O. freq to 10750MHz as shown below.

No Signal (Tuner 1)

The LNB at the left below has a L.O. of 10750MHz, if you have one of these you will need to take the steps shown on the next page:



10750 MHz



11300MHz




11300MHz

How to change the LNB L.O. frequency to 10750MHz

If you have the LNB shown on the left press **MENU** on your remote control then press **>** to select Installation.

Once you have pressed **MENU** you will see:



Now select Dish Setting and press **OK**.



Scroll down and Select 10750 for the LNB frequency and press **OK**.



Once saved you can exit and watch TV.